

First off let us say thanks for supporting AC with your hard earned dollars. We think you'll find that you've made an excellent choice.

⚠ WARNING: CYCLING CAN BE DANGEROUS. BICYCLE PRODUCTS SHOULD BE INSTALLED AND SERVICED BY A PROFESSIONAL MECHANIC. NEVER MODIFY YOUR BICYCLE OR ACCESSORIES. READ AND FOLLOW ALL PRODUCT INSTRUCTIONS AND WARNINGS INCLUDING INFORMATION ON THE MANUFACTURER'S WEBSITE. INSPECT YOUR BICYCLE BEFORE EVERY RIDE. ALWAYS WEAR A HELMET.

⚠ WARNING: A loose, cracked, or crashed pedal can break off of your bicycle crank leading to a loss of control that could cause serious injury. Pedals that are damaged should not be used. Remove immediately and inspect for damage. If you are unsure if your pedal is damaged, consult your local bike dealer.

Additional Product and Safety Information can be found at the website: www.allcitycycles.com/safety

Compatibility

All-City pedals are for 9/16" pedal threads. All of our pedals will accommodate toe clips and straps.

Intended Use

All-City pedals are designed for road and track riding. They are not intended for off-road use or stunt riding.

Required Tools

6mm Allen wrench

Pedal wrench

Grease for threads

NOTE: Never use a cone wrench to remove or install a pedal.

Installing Pedals

1. Begin by identifying the right and left pedals. Look for "L" and "R" marking on axle or wrench flats.

NOTE: Pedal spindle threads are different from left side and right side. The right side pedal has a right-hand thread (threads in clockwise) and is intended for use on the driveside of a bike (to the right when sitting on the bike). The left side pedal has a left-hand thread (threads in counterclockwise) for use on the non-driveside (to the left while seated).

⚠ CAUTION: Do not attempt to install a right-side pedal into the left-side crank or vice versa. Doing so could permanently damage your crank AND pedal. Left-threaded pedals (threads sloping upward to the left) go on the left crank. Right-threaded pedals (threads sloping upward to the right) go on the right crank. See image above if in doubt.

2. Heavily grease threads of both pedals.

3. Thread the right-side pedal into right crank by hand, CLOCKWISE.

4. To tighten fully, use the pedal wrench or 6mm Allen wrench. Torque to 18Nm.

5. Repeat these steps for the left-side pedal, making sure to tighten by turning COUNTER-CLOCKWISE.

NOTE: Periodically check both pedals for tightness and retighten according to these instructions if necessary.

⚠ WARNING: Immediately discontinue using the pedals if excessive play develops, the pedal body or spindle shows signs of cracking, or the pedal body seems too tight or too loose on the spindle. Take your bicycle or pedals to a professional bicycle mechanic for evaluation and service.



Limited Warranty

This All-City® product is warranted against defects in materials and workmanship for three years from the date of retail purchase of the product, subject to the limitations detailed below. Save your dated receipt for proof of purchase.

This warranty does NOT cover the following:

- Damage due to improper assembly or follow-up maintenance or lack of skill, competence or experience of the user or assembler
- Products that have been modified, neglected, used in competition or for commercial purposes, misused or abused, involved in accidents or anything other than normal use
- Installation of components, parts or accessories not originally intended for or compatible with All-City products
- Damage or deterioration to the paint, surface finish, aesthetics or appearance of the product
- Normal wear and tear
- Labor required to remove and/or refit and re-adjust the product within the bicycle assembly

This limited warranty is expressly limited to the repair or replacement of a defective product, at the option of All-City Cycles, and is the sole remedy of the warranty. This limited warranty applies only to the original purchaser of the All-City product and is not transferrable. This warranty applies only to products purchased through an authorized dealer or distributor. In no event shall All-City Cycles be liable for any loss, inconvenience or damage, whether direct, incidental, consequential, or otherwise resulting from breach of any express or implied warranty or condition, of merchantability, fitness for a particular purpose, or otherwise with respect to our products except as set forth herein. This limited warranty gives the consumer specific legal rights, and those rights and other rights may vary from place to place. This limited warranty does not affect your statutory rights.

TO THE EXTENT NOT PROHIBITED BY LAW, THESE WARRANTIES ARE EXCLUSIVE AND THERE ARE NO OTHER EXPRESS OR IMPLIED WARRANTIES OR CONDITIONS INCLUDING WARRANTIES OR CONDITIONS OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

Warranty Process

We will happily back up our products if there is a problem that is our fault. If you and your shop think your All-City product is worthy of a warranty inspection, please return the product to the original place of purchase, accompanied by a sales receipt.

Other Products

Check our website for the full range of All-City bikes, frames, parts and accessories.

Contact Us

Questions, comments, anecdotes, build pics and hipster jokes can and should be directed to:

All-City Cycles
6400 West 105th Street
Minneapolis, MN 55438

Phone: 1.888.4AC.BIKE
Web: www.allcitycycles.com
E-mail: info@allcitycycles.com

