www.allcitycycles.com

Toe Clip Instructions

Hey, thanks for supporting All-City and buying our stuff. We really appreciate it, and hope that you get years of use and enjoyment from your purchase. If there's ever anything we can do for you, let us know. Cheers

WARNING: CYCLING CAN BE DANGEROUS. BICYCLE PRODUCTS SHOULD BE INSTALLED AND SERVICED BY A PROFESSIONAL MECHANIC. NEVER MODIFY YOUR BICYCLE OR ACCESSORIES. READ AND FOLLOW ALL PRODUCT INSTRUCTIONS AND WARNINGS INCLUDING INFORMATION ON THE MANUFACTURER'S WEBSITE. INSPECT YOUR BICYCLE BEFORE EVERY RIDE. ALWAYS WEAR A HELMET.

Additional Product and Safety Information can be found at the website: www.allcitycycles.com/safety

Tools required

Phillips head screwdriver 9mm open end wrench

Compatibility

Verify with the pedal manufacturer that the pedal model will accommodate toe clips and straps.

Installation

- 1. Remove the front reflector attached to the pedal if present.
 - **NOTE:** We strongly recommend that the reflector be replaced by another reflector or a reflective surface such as an adhesive-backed tape.
- 2. Line up the boltholes or slots in the bottom of the metal clip with the bolt holes on front of the pedal.
- 3. Push the bolts through the clip and the pedal and tighten the nuts with a wrench or Allen key.

WARNING: Periodically check to make sure the toe clip bolts are tight. Loose toe clips could cause a loss of control that could result in a crash causing serious injury or even death.

Limited Warranty

This All-City® product is warranted against defects in materials and workmanship for three years from the date of retail purchase of the product, subject to the limitations detailed below. Save your dated receipt. This limited warranty is expressly limited to the repair or replacement of the original product, at the option of All-City, and is the sole remedy of the warranty. This limited warranty applies only to the original purchaser of the All-City product and is not transferable. In no event shall All-City be liable for any loss, inconvenience or damage, whether direct, incidental or consequential or otherwise resulting from breach of any express or implied warranty or condition, of merchantability, fitness for a particular purpose, or otherwise with respect to this product except as set forth herein. This warranty only applies to All-City branded product. Any other original part or component shall be covered by the stated warranty of the original manufacturer.

TO THE EXTENT NOT PROHIBITED BY LAW, THIS WARRANTY IS EXCLUSIVE AND THERE ARE NO OTHER EXPRESS OR IMPLIED WARRANTIES OR CONDITIONS OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE

This warranty does not cover the following:

- Damage due to improper assembly or follow-up maintenance or lack of skill, competence or experience
 of the user or assembler
- Products that have been modified, neglected, used in competition or for commercial purposes, misused
 or abused, involved in accidents or anything other than normal use
- Damage or deterioration to the surface finish, aesthetics or appearance of the product
- Normal wear and tear
- Labor required to remove and/or refit and re-adjust the product within the bicycle assembly

Other Products

Check our website for the full range of All-City bikes, frames, parts and accessories.

Contact Us

Questions, comments, anecdotes, build pics and hipster jokes can and should be directed to:

All-City Cycles 6400 West 105th Street Minneapolis, MN 55438

Phone: 1.888.4AC.BIKE Web: www.allcitycycles.com E-mail: info@allcitycycles.com

