

Hey, thanks for supporting All-City and buying our stuff. We really appreciate it, and hope that you get years of use and enjoyment from your purchase. If there's ever anything we can do for you, let us know.

All-City Toe Clips and Straps provide foot retention to keep your feet positioned for better power transfer through the pedals and to your wheel.

Cheers!

**⚠ WARNING:** CYCLING CAN BE DANGEROUS. BICYCLE PRODUCTS SHOULD BE INSTALLED AND SERVICED BY A PROFESSIONAL MECHANIC. NEVER MODIFY YOUR BICYCLE OR ACCESSORIES. READ AND FOLLOW ALL PRODUCT INSTRUCTIONS AND WARNINGS INCLUDING INFORMATION ON THE MANUFACTURER'S WEBSITE. INSPECT YOUR BICYCLE BEFORE EVERY RIDE. ALWAYS WEAR A HELMET.

Additional Product and Safety Information can be found at the website: [www.allcitycycles.com/safety](http://www.allcitycycles.com/safety).

## Toe Clip Compatibility

All-City Toe Clips are only compatible with pedals that have mounting holes in the cages of the pedal. DO NOT modify a pedal that does not have these mounting holes as it could cause structural damage to the pedal and make them unsafe to ride. Check with the pedal manufacturer or your local bicycle dealer for compatibility.

## Intended Use

All-City Toe clips are intended to be used with toe straps to hold your foot in a position that provides a better pedal stroke and more pedaling power. They will not work and ARE NOT TO BE USED on their own.

## Tools required

Screwdriver  
4mm or 5mm Allen wrench  
8mm open end wrench

## Installation

1. Remove the front reflector attached to the pedal if present. Line up the boltholes or slots in the bottom of the metal clip with the bolt holes on front of the pedal.
2. Push the bolts through the clip and the pedal and tighten the nuts with a wrench or Allen key. For certain pedal models, a bolt may fit a machined opening in the pedal such that no nut is necessary.

**⚠ WARNING:** Periodically check to make sure the toe clip bolts are tight. Loose toe clips could cause a loss of control that could result in a crash causing serious injury or even death.

## Toe Strap Compatibility

All-City Toe Straps are intended for road or track riding and for pedals that have slots in the spindle body behind the spindle towards the back and/or slots in the pedal cage. Using toe straps on pedals without these slots will not work, and will make the pedals dangerous to ride.

## Intended Use

All-City Toe Straps are intended to be used with toe clips to hold your foot in a position that provides a better pedal stroke and more pedaling power. They will not work and ARE NOT TO BE USED on their own.

## Installation

1. Feed the free end of the strap through the slot in the pedal cage, beginning at the side away from the bottom bracket, also called the non-axle side. Pull it with pliers if it is too tight to move with just your fingers.
2. Thread the strap through the opening or openings at the top of the clips. Check if the buckle end of the strap is about 2" from the pedal's outside edge.
3. Feed the strap through the buckle and snug the straps so that the strap fits comfortably.
4. Make adjustments to the straps so that they are securely fastened to the pedal and your foot, but loose enough so that you can safely react and remove your foot from the pedals and straps if and when necessary.

5. Repeat steps 1–4 for the second pedal and strap.

6. Periodically check both pedals and straps for tightness and proper function.

**NOTE:** For street riding, the straps should not be as tight if they were if you were sprinting in the velodrome or in a road race.

**⚠ WARNING:** Periodically check to make sure the toe clip bolts are tight. Loose toe clips could cause a loss of control that could result in a crash causing serious injury or even death.

## Limited Warranty

This All-City® product is warranted against defects in materials and workmanship for three years from the date of retail purchase of the product, subject to the limitations detailed below. Save your dated receipt for proof of purchase.

This warranty does NOT cover the following:

- Damage due to improper assembly or follow-up maintenance or lack of skill, competence or experience of the user or assembler
- Products that have been modified, neglected, used in competition or for commercial purposes, misused or abused, involved in accidents or anything other than normal use
- Installation of components, parts or accessories not originally intended for or compatible with All-City products
- Damage or deterioration to the paint, surface finish, aesthetics or appearance of the product
- Normal wear and tear
- Labor required to remove and/or refit and re-adjust the product within the bicycle assembly

This limited warranty is expressly limited to the repair or replacement of a defective product, at the option of All-City Cycles, and is the sole remedy of the warranty. This limited warranty applies only to the original purchaser of the All-City product and is not transferrable. This warranty applies only to products purchased through an authorized dealer or distributor. In no event shall All-City Cycles be liable for any loss, inconvenience or damage, whether direct, incidental, consequential, or otherwise resulting from breach of any express or implied warranty or condition, of merchantability, fitness for a particular purpose, or otherwise with respect to our products except as set forth herein. This limited warranty gives the consumer specific legal rights, and those rights and other rights may vary from place to place. This limited warranty does not affect your statutory rights.

TO THE EXTENT NOT PROHIBITED BY LAW, THESE WARRANTIES ARE EXCLUSIVE AND THERE ARE NO OTHER EXPRESS OR IMPLIED WARRANTIES OR CONDITIONS INCLUDING WARRANTIES OR CONDITIONS OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

## Warranty Process

We will happily back up our products if there is a problem that is our fault. If you and your shop think your All-City product is worthy of a warranty inspection, please return the product to the original place of purchase, accompanied by a sales receipt.

## Other Products

Check our website for the full range of All-City bikes, frames, parts and accessories.

## Contact Us

Questions, comments, anecdotes, build pics and hipster jokes can and should be directed to:

All-City Cycles  
6400 West 105th Street  
Minneapolis, MN 55438

Phone: 1.888.4AC.BIKE  
Web: [www.allcitycycles.com](http://www.allcitycycles.com)  
E-mail: [info@allcitycycles.com](mailto:info@allcitycycles.com)

